

FIG. 1

AT	AID=0000	AID=0001	AID=0002		AID=FFFF
00	ART_EXAMPLE			
01					
02					
	:	:	:		:
	:	:	:		:
	:	:	:		:
FE					
FF					


ADAPTER - TYPE / ADAPTER - ID TO ADAPTER - RESOURCE TABLE ADDRESS
FIG. 2A

RT	ART_EXAMPLE
00	ART ENTRY0
01	ART ENTRY1
02	ART_EXAMPLE ENTRY FOR CQ RESOURCE TYPE
03	
	:
	:
	:
FF	ART ENTRY255

ADAPTER RESOURCE TABLE (ART)
FIG. 2B

DWORD		ART_EXAMPLE ENTRY FOR CQ RESOURCE TYPE			
0	ASAB		PRC	MRC	
1	SAC	RESERVED	SMC	RESERVED	
2	RESERVED	LARID		RESERVED	RIL
3	ACCESS-TABLE ADDRESS (ATA) - AT IS FOR ALL CQ RESOURCES				RESERVED
4	ADAPTER-STORAGE BASE ADDRESS FOR SAT=0				RESERVED
5	ADAPTER-STORAGE BASE ADDRESS FOR SAT=1				RESERVED
6-18	⋮				RESERVED
19	ADAPTER-STORAGE BASE ADDRESS FOR SAT=15				RESERVED
BITS		0	8	16	32 40 52 63
ADAPTER - RESOURCE - TABLE ENTRY (ARTE)					

ADAPTER - RESOURCE - TABLE ENTRY (ARTE)
FIG. 2C



RESOURCE ADDRESS TRANSLATION

FIG. 3